



genuine original spare parts



EN Check the alternating voltage at the pcb output with the tester.

FR Vérifier la tension alternative à la sortie de la carte avec le testeur.











IT Controllare la tensione alternata all'uscita scheda con il tester.




ES Verifique el voltaje alterno en la salida de la tarjeta electrónica con el *prufo* *multímetro*.

DE Mit dem Tester die Wechselspannung am Elektronikplatinen prüfen.


NL Controleer de wisselspanning op de elektronische kaart met de tester.




1




2




3




4




5



6



7



8

